

## WOCA Color Oil

Color Oil colors and protects in one application and is suitable for all wood species. Color Oil may be used on unfinished or freshly sanded wood floors and interior woodwork. The oil brings out the natural wood grain and gives a hardwearing surface, which is easy to maintain.

Color Oil is available in 1 and 2.5 liter containers and in the colors light brown, brazil brown, red brown, tea-chest brown, rhode island brown, walnut, castle grey, extra grey, extra white, bordeaux, cream, brandy, antik, and black.



### Tools Required

A floor buffer with red and white polishing pads, paint roller and cotton cloths.

### ***Please notice!***

*Risk of self-ignition! Due to the risk of self-ignition it is important that sanding dust and oil wetted cloths are soaked in water and disposed of in a tightly closed container after use.*

### How to do...

It is recommended to use a floor buffer for the oil application. Recommended wood moisture maximum - 12%. The oiling should be done at a minimum temperature of 60° F.

**1** The floor or woodwork should be freshly sanded and completely clean, dry, and free from stains before the application of the Color Oil. Clean the floor with a solution of 1/4 cup Wood Cleaner per gallon water.

**2** Shake the container with Color Oil well before and during application. Apply the oil in an even coat with a low nap paint roller onto an area of 100 - 200 sq. ft. Let the floor absorb the oil for 20 minutes. Subsequently, the oil is worked into the wood with a red pad either manually or for large areas with a buffer. Polish until the floor appears saturated with oil.

**3** Excess oil is removed with lint free cloths or scraped with a squeegee onto next section of floor to be oiled. Then buff the floor with lint free cloths under white polishing pads. The floor should not appear wet and no excess oil should be left on the surface after polishing. Continue in sections until the whole floor has been finished.



**4** After 6 - 8 hours, or when dry enough to walk on, the floor should be buffed with a white polishing pad and color oil. If a silk matte surface is required, the finished floor may be buffed with 1 liter of Color Oil to 500 - 600 s.f. of floor. The oil must be polished carefully into the floor. No excess oil should be left on the surface. After 6 - 8 hours, cover walking areas with corrugated cardboard for the 72 hours hardening period. Do not expose the floor to water during the hardening time.

